

POWERFLEX®

PART NUMBER

PFR3-122

DESCRIPTION

REAR SUBFRAME MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

8 x Polyurethane Bushes 4 x Washers
4 x Stainless Steel Sleeves 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber bush from the rear subframe, clean any dirt and corrosion from the bore in the subframe. Using a file, remove any sharp edges from around the bore of the arm creating a small chamfer.

2. Push the PU bush into the top and bottom of the bore of the rear subframe, repeat for each of the mounting points on the subframe.

3. Apply some of the supplied grease to the bore of the polyurethane bush and insert the sleeve into the bore of the bush.

4. When refitting the arm back to the vehicle ensure to place a washer on the bottom side of the bush, as shown in figure 1. Then tension all hardware to manufacturers recommended torque settings




Figure 1